


# CRH1832BLC



NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	PROTECTION SLEEVE ASSY	6-4	BIG GEAR	15-1	BEVEL GEAR
1-1	PROTECTION CAP	6-5	PIN	15-2	BEARING 607Z
1-2	WASHER	6-6	CLUTCH DISK	16	SCREW M4X12
1-3	CIRCLIP	6-7	CIRCLIP	17	Φ4 SPRING WASHER
1-4	LOCATION RING	6-8	ROTARY SLEEVE	18	PRESSURE PLATE
1-5	CIRCLIP 19×2	6-9	GUIDE BUSHING	19	LED LIGHT COVER
1-6	PROTECTION SLEEVE	6-10	O-RING	20	SCREW ST3.9×16
1-7	WASHER	6-11	O-RING	21	HOUSING
1-8	STEEL BALL Ø7.14	6-12	DAMPING BUSHING	22	FORWARD/REVERSE BUTTON
1-9	WASHER	6-13	CIRCLIP	23	ROTOR (WITH 607Z BEARING)
1-10	SPRING	7	CYLINDER ASSY	24	STATOR ASSY
2	DRILL SLEEVE ASSY	7-1	PISTON	24-1	STATOR
2-1	DRILL SLEEVE	7-2	O-RING	24-2	WIRING BOX
2-2	O-RING	7-3	CYLINDER	24-3	WIRING BOX COVER
2-3	OIL SEAL	7-4	WASHER	24-4	SCREW ST2.2X10
2-4	THRUST RING	7-5	PIN	24-5	SWITCH
2-5	IMPACT ROD	8	BRACKET ASSY	24-6	MOTOR PCB
3	SCREW ST4.8×40	8-1	BUSHING	24-7	WIRE
4	GEAR HOUSING ASSY	8-2	BRACKET	24-8	CONNECTION FOOT
4-1	GEAR HOUSING	8-3	WOOL FELT	25	RUBBER COLUMN
4-2	OIL SEAL	8-4	O-RING	26	BEARING PRESSURE PLATE
4-3	BEARING SLEEVE ASSY	8-5	BRACKET PIN	27	AUXILIARY HANDLE ASSY
4-3-1	NEEDLE BEARING HK3012	8-6	BALL BEARING 609RS	27-1	CLAMPING BAND
4-3-2	BEARING SLEEVE	8-7	BEARING PRESS PLATE	27-2	T- BOLT
4-4	NEEDLE BEARING HK0709	8-8	SCREW M4×10	27-3	CLAMP HOLDER
4-5	WASHER	9	MIDDLE GEAR ASSY	27-4	CLAMP
4-6	SCREW ST4.2×13	9-1	MIDDLE GEAR	27-5	SPRING
5	SELECTOR KNOB ASSY	9-2	BEARING 699	27-6	AUXILIARY HANDLE
5-1	LOCKING BUTTON	10	SHIFT FORK	28	DEPTH RULER
5-2	SPRING	11	SNAP RING	29	O-RING
5-3	SELECTOR KNOB	12	ROCKER BEARING ASSY	30	PIN
5-4	O-RING	12-1	NEEDLE BEARING HK0908	31	WASHER
6	ROTARY SLEEVE ASSY	12-2	ROCKER BEARING	32	BATTERY PACK
6-1	CIRCLIP	13	CLUTCH	33	CHARGER
6-2	WASHER	14	SPRING		
6-3	SPRING	15	BEVEL GEAR ASSY		