



CS51190

NO.	DESCRIPTION	NO.	DESCRIPTION
1	CROSS HEAD SCREW M5*14	36	WINDSHIELD
2	GEAR HOUSING COVER	37	CROSS HEAD TAPPING SCREW ST5*58
3	TERMINAL CAP	38	STATOR
4	HEX SOCKET SCREW M8*14	39	LEFT HANDLE
5	FLAT WASHER8 (Φ8.5*Φ18×2)	40	CODE PROTECTOR
6	OUTER FLANGE	41	SWITCH
7	BLADE 190*20*2.4*24T	42	LEFT AND RIGHT PUTTER
8	INNER FLANGE	43	SWITCH SPRING Φ6.6*Φ0.6*20
9	DIAL BUTTON	44	PCB SPEED CONTROL ROD
10	DOUBLE SHAFT RETAINING RING	45	RIGHT HANDLE
11	MOVABLE GUARD	46	BASE PIN
12	CROSS HEAD TAPPING SCREW ST4*16	47	ANGLE BRACKET
13	TORSION SPRING Φ47.5*Φ1.5*7.5	48	SHAFT RETAINING RING Φ7
14	CROSS HEAD SCREW M4 X 12	49	LOCK KNOB
15	FRONT COVER	50	SEMI-HOLLOW RIVET Φ8×18
16	BALL BEARING 6001-2RS	51	FLAT WASHER Φ8.2*Φ14 * 0.3
17	HOLE RETAINING RING 28	52	DEPTH SUPPORT
18	SPINDLE	53	FLAT WASHER Φ6 X Φ16 X 1
19	FLAT KEY 5×5×10	54	DEPTH LOCKING LEVER
20	GEAR	55	DEPTH LOCKING KNOB
21	SHAFT RETAINING RING Φ15	56	GUIDE RULER LOCK KNOB
22	OIL BEARING Φ12*Φ8*10	57	BASE
26	SQUARE SCREW M6*22	58	BRUSH HOLDER
27	GEAR HOUSING	59	CARBON BRUSH
28	CROSS HEAD SCREW M6*18	60	CABLE
29	LIMIT RUBBER COLUMN	61	CROSS HEAD TAPPING SCREW ST4*22
30	ELASTIC CYLINDRICAL PIN Φ4*25	62	BUTTON CELLS
31	SELF-LOCKING SPRING Φ11.8*Φ0.7*27	63	DUST EXTRACTION ADAPTOR
32	SELF-LOCKING	64	PARALLEL GUIDE
33	BALL BEARING 6001-2RZ	65	HOUSING
34	ROTOR	66	REAR COVER
35	BALL BEARING 608-2Z		

CS51190 ex -RU240816

Sturmm!
нас рекомендуют друзья