


EL1432



NO.	DESCRIPTION	NO.	DESCRIPTION
1	UPPER HANDLE	32	SAND
2	WING NUT	33	COUNTER WEIGHT
3	PLUG OF PUSH ROD	34	BOLT
4	BOLT	35	SPRING WASHER
5	LOWER HANDLE (LEFT)	36	Φ 8 WASHER
6	REAR COVER	37	BLADE
7	SPRING OF REAR COVER	38	LAWN MOWER FRONT WHEEL SHAFT
8	HANDLE OF COVER	39	LAWN MOWER REAR WHEEL SHAFT
9	MOTOR COVER	40	SPONGE
10	ST4.2*16-F BOLT	42	COLLECTION BOX
11	AC MOTOR	43	COVER OF GRASS BAG
12	Φ9 RING	44	FULL GRASS INDICATE
13	SMALL BELT PULLEY	45	COVER HANDLE
14	609ZZ BEARING	46	CABLE CLIP1
15	M6 NUT	47	LOWER HANDLE (RIGHT)
16	TRANSMISSION BRACKET	48	CABLE CLIP2
17	6002RS BEARING	49	UPPER COVER OF SWITCH
18	LARGE BELT PULLEY	50	SWITCH BOX BUTTON
19	MULTI-WEDGE BAND 2	51	SWITCH
20	ST4.8*19-C SCREW WITH WASHER	52	WIRE PRESSING PLATE
21	SPONGE 1	53	SPRING OF SWITCH BOX
22	SPONGE	54	SWITCH BOX TRIGGER
23	SPONGE 2	55	TORSION SPRING OF SWITCH BOX
24	ST4.2*16-C BOLT	56	BOTTOM COVER OF SWITCH
25	DECK	57	CABLE ASSEMBLY
26	HEIGHT ADJUSTMENT SPRING	58	CABLE
27	140MM WHEELS	59	SWITCH BOX FIXED COVER
28	WASHER	60	ST4.2*19-F BOLT
29	2.0 * 16 PIN	Z1	SWITCH BOX ASSEMBLY
30	PLUG OF WHEEL	Z2	REDUCTION GEAR BOX ASSEMBLY
31	SPONGE		