


## GE168-19Q/GE170-20S



NO.	DESCRIPTION	NO.	DESCRIPTION
A1	CLIP TUBE	A56	NUT TOOL BOX SETTING
A2	TUBE FUEL	A57	COVER AIR CLEANER
A3	JOINT ASSY FUEL TANK	A58	SEAL AIR CLEANER
A4	CAP COMP FUEL FILLER	A59	COVER AIR CLEANER
A5	FILTER FUEL	A60	FILTER OUTER
A6	TANK COMP FUEL	A61	NOSE SILENCER
A7	SPRING THROTTLE RETURN	A62	ELBOW COMP AIR CLEANER
A8	SPRING THROTTLE RETURN	A63	BOLT FLANGE 6*25
A9	ARM GOVERNOR	A64	COIL ASSY IGNITION
A10	NUT FLANGE	A65	PIN DOWER
A11	PIN LOCK	A66	BOLT FLANGE 8*55
A12	SHAFT GOVERNOR ARM	A67	SPACER COMP AIR CLEANER
A13	ROD GOVERNOR	A68	LEVER COMP CHOKE
A14	BOLT FLANGE	A69	CARBURETOR
A15	BOLT QUADRATE HEAD	A70	PACKING CABURETOR
A16	CONTROL ASSY	A71	INSULATOR CARBURETOR
A17	WASHER PAIN	A72	PACKING INSUL ATOR
A18	KNOB RECOIL STARTER	A73	BOLT STUD IN
A19	COVER COMP FAN	A74	TUBE BREATHER
A20	SPRING RECOIL SATRTER	A75	COVER COMP HEAD
A21	REEL RECOIL STARTER	A76	PACKING HEAD COVER
A22	ROPE	A77	RATATOR VALVE
A23	SPRING RETURN	A78	SEAL GUIDE
A24	RATCHET STARTER	A79	RETAINER VALVE SPRING
A25	GUIDE RATCHET	A80	SPRING VALVE
A26	SCREW SETTING	A81	PLUG SPARK
A27	SWITCH ASSY ENGINE STOP(OIL ALERT)	A82	HEAD COMP CYLINDER
A28	COVER COMP FAN	A83	GASKET CYLINDER
A29	NUT SPECIAL	A84	VALVE IN
A30	PULLEY STARTER	A85	VALVE EX
A31	FAN COOLING	A86	LEFTER VALVE
A32	FLYWHEEL COMP	A87	CAMSHAFT ASSY
A33	DIVERSION ASSY	A88	PIN FLYING BLOCK
A34	OIL SEAL25*41.25*6	A89	NUT PIVOT ADJUSTING
A35	PLATE SIDE SUPPORT	A90	PIVOT ROCKER ARM
A36	ALART UNIT OIL	A91	ARM VALVE ROCKER
A37	BOLT DRAIN PLUG	A92	BOLT PIVOT ARM
A38	WASHER DRAIN PLUG 10*15*1.2	A93	PLATE ASSY
A39	CRANK CASE	A94	ROD PUSH
A40	BEARING RADIAL BALL	A95	KEY SPECIAL WOODRUFF
A41	OIL LEVEL SWITCH	A96	SCREW TAPPING 5*8
A42	GEAR GOVERNOR	A97	PROTECTOR MUFFLER
A43	PIN GOVERNOR WEIGHT	A98	MUFFLER ASSY
A44	SHAFT GOVERNOR	A99	NUT HEX 8MM
A45	CLIP GOVERNOR HOLDER	A100	GASKET MUFFLER
A46	WEIGHT GOVERNOR	A101	BOLT STUD EXHAUST
A47	WASHER PAIN 6*15*0.5	A102	SHROUD
A48	SLIDER GOVERNOR	A103	RING SET
A49	CRANKSHAFT COMP	A104	PISTON
A50	PACKING CASE COVER	A105	CLIP PISTON PIN
A51	OIL FILLER CAP	A106	PIN PISTON
A52	PACKING OIL FILLER CAP	A107	CONNECTING ROD
A53	COVER	A108	OIL STICK
A54	BOLT FLANGE	A201	RECOIL STARTER COMP
A55	BOLT FLANGE	A202	AIR CLEANER COMP
		A203	MUFFLER COMP