



GK8210GP

NO.	DESCRIPTION	NO.	DESCRIPTION
1	BOLT M10×35	46	O-RING
2	SPRING WASHER Φ10	47	BOLT M8X25
3	WASHER Φ10	48	SPRING WASHER Φ8
4	SPINDLE GUARD	49	PRESSURE RELIEF BOLT
5	BOLT M8×16	50	FLANGE PLATE
6	CLUTCH CABLE BLOCK	51	GASKET
7	TRANSMISSION BOX ASSY.	52	GASOLINE ENGINE
8	HANDLE FRAME	53	BUMPER SUPPORT
10	NUT M6	54	BOLT M10X50
11	BOLT M6×16	55	FRONT SUPPORT
12	HANDLE SLEEVE	56	TENSION SPRING
13	CLUTCH HANDLE	57	NUT M10
14	SPRING PIN	58	BOLT M10X40
15	WASHER Φ6	59	ENGINE SUPPORT
16	BOLT M6×30	60	DUST COVER
17	PIN Φ6X30	61	BOLT M8X16
18	CLUTCH CABLE	62	HEXAGONAL FIXING SLEEVE
19	GEAR SHIFTING CONNECTION ROD	63	HEXAGONAL OUTPUT SHAFT
20	SPRING PIN	64	BOLT M12X50
21	LOCKING HANDLE SLEEVE	65	NUT M12
22	LOCKING HANDLE	66	CONNECTOR ASSEMBLY
23	SPRING WASHER Φ16	67	PIN Φ8X40
24	WASHER Φ16	68	TRAILER BODDY ASSEMBLY
25	BOLT M16X150	69	BIG PIN
26	SPRING PIN	70	NUT M10
27	WASHER Φ12	71	SPRING PIN
28	GEAR SHIFTING CONTROL ROD	72	RESISTANCE BAR
29	GEAR SHIFTING CONTROL ROD HANDLE	73	BOLT M10X25
30	SCREW M5X30	74	WASHER Φ6
31	THROTTLE SWITCH	75	FENDER REAR BRACKET
32	NUT M5	76	RIGHT FENDER
33	SPRING PIN	77	RIGHT SAMLL FENDER
34	STOP SWITCH CABLE	78	LEFT SAMLL FENDER
35	RIVET Φ3.2X9	79	RIGHT FENDER FRONT BRACKET
36	LABEL	80	LEFT FENDER
37	HANDLE STAND	81	LEFT FENDER FRONT BRACKET
38	CLUTCH HOUSING	82	BOLT M10X30
39	BEARING 6007	83	NUT M10
40	GASKET	84	SPRING WASHER Φ10
41	BOLT M8X25	85	RIGHT BLADE
42	REVERSE HANDLE	86	LEFT BLADE
43	PIN Φ7X22	87	BLADE SPINDLE
44	PIN Φ10X22	88	PIN Φ8X50
45	REVERSE HANDLE CABLE		

ENGINE FOR GK8210GP



NO.	DESCRIPTION	NO.	DESCRIPTION
1	RECOIL STARTER ASSY.	49	CYLINDER HEAD GASKET
1-1	STARTER	50	AIR FILTER
1-2	COVER FAN	50-1	AIR FILTER COVER
2	BOLT M6×8	50-2	FILTER
3	BOLT M6×12	50-3	AIR FILTER SEAT
4	NUT M16×1.5	51	AIR FILTER GASKET
5	STARTER CUP	52	CARBURETOR
6	SWITCH	53	BREATH PIPE
7	FAN	54	CARBURETOR GASKET
8	FLY WHEEL	55	BLOCK BOARD
9	BOLT M6X25	56	DOUBLE BOLT
10	IGNITION	57	GASKET
11	BOLT M12×1.5X15	58	CLIP
12	WASHER Φ20XΦ12X1.5	59	FUEL PIPE
13	OIL SEAL	60	CYLINDER HEAD
14	THREADING BLOCK	61	COOL GUIDE BOARD
15	CRANK BOX	62	DOUBLE BOLT
16	SEPARATOR	63	MUFFLER GASKET
17	WIRE CLAMP	64	EXHAUST PIPE
18	OIL ALARM	65	EXHAUST PIPE GASKET
19	BOLT M6X16	66	SPRING WASHER Φ8
20	CRANK SHAFT	67	NUT M8
21	PIN Φ8X14	68	MUFFLER
22	CRANK BOX GASKET	69	NUT M8
23	RETE-LIMITING GEAR ASSY.	70	BOLT M8X25
24	BEARING 6206	71	FUEL TANK
25	OIL PLUG	71-1	FUEL FILTER
26	CRANK BOX COVER	72	FUEL TANK CAP
27	OIL GAUGE	73	BOLT M10X1.25X80
28	BOLT M8X40	74	SPARK PLUG
29	CAMSHAFT	75	INTAKE VALVE
30	ROD	76	EXHAUST VALVE
31	PUSH ROD	77	VALVE OIL SEAL
32	SWINGING ROD	78	LOWER VALVE SEAT
33	WASHER Φ8	79	VLAVE SPRING
34	OIL SEAL	80	INTAKE VALVE SPRING BASE
35	SPRING PIN	81	EXHAUST VALVE SPRING BASE
36	CONTROL ARM	82	TOP COVER
37	T-BOLT M6X21	83	GUIDE BOARD
38	NUT M6	84	ROCK ARM ASSY.
39	CONNECT ROD	85	CYLINDER HEAD GASKET
40	PISTON PIN	86	CYLINDER HEAD COVER
41	PISTON	87	BOLT M6X60
42	PISTON PIN CIRCLIP	88	BOLT M6X12
43	SMALL TENSION SPRING	89	FUEL PIPE FILTER
44	SPEED CONTROL LEVER	90	BOLT M6X20
45	BIG TENSION SPRING		
46	PISTON RING ASSY.		
47	SPEED CONTROL		
48	PIN Φ12X20		