



## HAG95151P

NO.	DESCRIPTION	NO.	DESCRIPTION
1	OUTPUT SHAFT	23	BEARING 608
2	SCREW M5X16	24	WIND FENDER
3	DUSTPROOF COVER	25	TAPPING SCREW ST5X60
4	FRONT COVER	26	STATOR
5	BEARING 6202	28	HOUSING
6	CIRCLIPS FOR HOLE Ø35	29	CARBON BRUSH HOLDER
7	WOODRUFF KEY 3.9X13	30	CARBON BRUSH
8	BIG GEAR	31	BRUSH COVER
9	NUT M14	32	TAPPING SCREW ST4X18
10	CIRCLIPS FOR SHAFT Ø12	33	SWITCH RIGHT HANDLE
11	SELF-LOCK PIN	34	SWITCH
12	SELF-LOCK SPRING	35	CABLE CLAMP
13	BEARING 607	36	CORD GUARD
14	TAPPING SCREW ST5X35	37	CABLE & PLUG
15	SELF-LOCK CAP	38	TAPPING SCREW ST4X14
16	GEAR HOUSING	39	SWITCH LEFT HANDLE
17	NUT M7	40	INDUCTANCE
18	SMALL GEAR	41	CAPACITANCE
19	BEARING 6201	43	SIDE HANDLE
20	MIDDLE COVER	45	DISC GUARD
21	ROTOR	46	LOWER FLANGE
22	DUSTPROOF CIRCLE	47	UPPER FLANGE
		48	BEARING BUSH
		49	BOLT

RU-HS20190319