


# hanskonner®

## HCD20420BLC



NO.	DESCRIPTION
1	SCREW ST4.0X20
2	CIRCLIP
3	O-RING
4	OUTPUT SHAFT
5	GEAR BOX
6	WASHER $\Phi 18 \times \Phi 32 \times 1$
7	IMPACT BLOCK
8	STEEL BALL $\Phi 3$
9	WASHER
10	SPRING
11	INTERMEDIATE SHAFT
12	STEEL BALL $\Phi 4.7$
13	PLANET GEAR
14	PIN $\Phi 5 \times 8$
15	GEAR RING
16	WASHER $\Phi 12 \times \Phi 21 \times 0.5$
17	O-RING
18	BEARING 6901RS
19	GEAR RING COVER
20	SEALING GASKET
21	ROTOR
22	STATOR
A23	RIGHT HOUSING
24	REAR COVER
25	SCREW ST3X14
26	DIRECTION SWITCH
27	SWITCH
28	LED COVER
29	SPEED CONTROL BUTTON
30	MOTOR PCB
31	CONNECTION FOOT
32N	BATTERY PACK
A33	LEFT HOUSING
A34	RIGHT LOWER HOUSING
A35	LEFT LOWER HOUSING
A36	HOOK
A37	SCREW ST5X10
A38	RUBBER COLUMN
A39	HANG ROPE
ACN	CHARGER

HCD20420BLC-EX-RU260417 ver2.1