


HGC4516/HGC5218

No	Description	No	Description
1	Air filter double side buckle	39	Throttle trigger
2	Air filter small cover	40	Trigger torsion spring
3	Front fender	41	Cylindrical pin 6X28
4	Screw M5X14	42	Trigger control arm
5	Screw ST5X18	43	Oil pipe 2.5X5X130
6	Air filter cover	44	Oil bubbles
7	Handle	45	Screw M5X12
8	Screw ST5X14	46	Boat switch + flameout line combination
9	Wind deflector	47	Screw ST5X18
10	Screw ST4X8	48	Sleeve fixing spring
11	Small dust cover	49	Screw ST4X8
12	Starter handle	50	Sleeve limit spring
13	Starting rope (%c3X900)	51	Slotted socket
14	Starter cover	52	Oil shot
15	Screw M5X18	53	Fuel cap seal O-type
16	Three hole pad	54	fuel tank cap
17	Single start coil spring	55	Brake spring pressure plate
18	Coil spring cover	56	Screw ST4X10
19	Big pulley	57	Chain guide block
20	Easy start large coil spring	58	Tensioner cover
21	Pan head self tapping ST3X8	59	Adjustment screw
22	Small pulley	60	Adjusting screw pin
23	Flat washer 5X15X1.2	61	Adjusting screw buckle
24	Screw ST4X16	62	Cylindrical pin 3X8
25	Air deflector	63	Brake band (406.5)
26	Tower spring	64	Brake pad
27	Cone spring seat	65	Flange nut M8 (coarse thread)
28	Chain block	66	Brake main spring
29	Screw M5X13	67	Brake band connecting rod
30	Big dust cover	68	Brake lever connecting piece
31	Long shock absorption	69	Brake lever
32	Tank	70	E-type circlip %c4
33	Double-ended pin	71	Round head solid rivet 3X9
34	Balancer seat	72	Round head solid rivet 3X13
35	Balancer	73	Chain
36	Fuel filter	74	Bar
37	Dual fuel pipe	75	Bar protector
38	Rear handle cover		

HGC4516/HGC5218-EX-RU250604

HGC4516/HGC5218



No	Description	No	Description
1	Keep circle	48	Intake flange
2	Screw M5x12	49	Carburetor
3	Intake pipe	50	Throttle push rod
4	Intake pipe paper pad	51	Intake elbow
5	Cylinder	52	Intake elbow shock absorber
6	Spark plug	53	Screw M5X50
7	Screw M5X20	54	Stud M5%x38
8	Bolt M5X85	55	Air filter gasket
9	Muffler paper pad	56	Double layer nylon air filter
10	Silencer	57	Butterfly buckle lock nut
11	Screw M5X14	58	Screw M5%x14
12	Muffler cover	59	Air door lever
13	Nut M5	60	Air door pull rod shock absorber
14	Cylinder paper gasket	61	Oil seal% ^o c15%x% ^c 28%x5
15	Piston rings	62	Oil pump cover
16	Piston	63	Screw M4%x10
17	Piston pin retaining ring% ^c 11	64	Worm gear
18	Piston pin	65	Needle roller bearing 12X15X14.5
19	Needle roller bearing 11X15X12.5	66	Sprocket
20	Crankshaft	67	Passive disk
21	Anti-wear pads	68	Clutch gasket
22	Woodruff key 3X3.7X10	69	Clutch assembly
23	Spark plug cap	70	Screw M4%x14
24	High voltage package	71	Fuel injector
25	Screw M5X18	72	Oil pump
26	Oil shot	73	Oil pump sponge
27	Oil cap seal O-ring	74	Oil pipe
28	Oil tank cap	75	Oil filter
29	Screw M5X30	76	Injector cover
30	Flywheel	77	Chain guide block
31	Flange nut M8-fine thread	78	Stud M8x42
32	Screw M4X8	79	Screw M5X10
33	Oil seal pressure plate	80	Wood cutting teeth
34	Oil seal% ^c 15%x% ^c 35%x5	81	Ventilation sponge
35	Inner retaining ring% ^c 35	82	Vent nozzle retaining ring % ^c 10
36	Deep groove ball bearings	83	Breather
37	Short shock absorption	84	Anti-scalding tube % ^c 7X70
38	Left box	85	Negative pressure tube
39	Left double-pin shock absorber	86	Negative pressure nozzle retraction spring
40	Box paper pad	87	Negative pressure mouth
41	Positioning pin% ^c 5X10	88	Front baffle metallurgical nut M5
42	Dustproof plate (rubber)	89	Limit push rod return spring
43	Right box	90	Screw M4X10
44	Right double-pin shock absorber	91	Limiting ejector rod
45	Bottom paper pad	92	Brake positioning block
46	Carburetor bracket	93	Bolt M5X18
47	Carburetor bracket gasket		