



hanskonner® HGC5820

No	Description	No	Description	No	Description
1	Hexagon socket screw	53	Limit push rod return spring	109	Rear handle cover
2	Starter handle	54	Limit ejector return spring cover	110	Fuel filter
3	Starter cover	55	Breather	111	Balancer
4	Single start coil spring	56	Ventilation sponge	112	Balancer seat
5	Coil spring cover	57	Vent nozzle retaining spring	113	Throttle push rod
6	Start rope	58	Slotted special-shaped bolts	114	Dual fuel pipe
7	Big pulley	59	Chain guide block	115	Throttle trigger
8	Easy start big coil spring	60	Big flat head cross slotted screw	116	Trigger torsion spring
9	Pan head tapping screws with washer	61	Oil filter	117	Cylindrical pin
10	Small pulley	62	Chain block	118	Fuel cap seal
11	Flat pad	63	Oil pipe	119	Fuel tank cap
12	Cross pan head tapping screws	64	Double-ended stud	120	Handle
13	Air deflector	65	Injector cover	121	Handle bracket
14	Oil tank cap	66	Fuel injector	122	Front fender
15	Oil cap seal	67	Oil pump	123	Hexagon socket head screw
16	Oil tank side cover	68	Oil pump sponge	124	Air filter cover
17	Oil shot	69	Hexagon socket screw	125	Oil bubbles
18	Oil tank side cover gasket	70	Oil pump cover	126	Air filter lock nut
19	Hexagon socket screw	71	Turbine	128	Air filter small cover
20	Flange face nut	72	Needle roller bearings	129	Air filter pressure plate
21	Magnetic flywheel	73	Sprocket	130N	Non-woven fabric air filter
22	Hexagon socket screw	74	Passive disk	131	Ship type switch
23	Conduit	75	Clutch gasket	132	Hex nut
24	Aluminum shock absorber spring cover	76	Clutch assembly	133	Muffler heat shield
25	Big flat head self tapping screws	79	Wood cutting teeth	134	Mars Catching Net
26	Shock absorber spring	80	Brake spring pressure plate	135	Silencer
27	Oil seal	81	Big flat head cross screw	136	Muffler paper pad
28	Hexagon socket screw	82	E type circlip	137	Square head bolt
29	Shock absorber spring cover	83	Brake lever	138	Hexagon socket screw
30	Left box	84	Brake lever connecting piece	139	High voltage package
31	Deep groove ball bearings	85	Brake band connecting rod	140	Spark plug
32	Dustproof board	86	Brake band	141	Cylinder
33	Bottom paper pad	87	Positioning pin	142	Hexagon socket screw
34	Negative pressure mouth	88	Hexagon socket screw	143	Intake pipe paper pad
35	Negative pressure nozzle retraction spring	89	Round head solid rivets	144	Intake pipe
36	Negative pressure tube	90	Round head solid rivets	145	Pan head Phillips screw
37	Ground wire	91	Brake main spring	146	Carburetor bracket
38	Anti-scald tube	92	Tensioner cover	147	Air door pull shock absorber rod sleeve (small)
39	Cylindrical pin	93	Adjusting screw pin	148	Air door pull shock absorber rod sleeve (big)
40	Piston rings	94	Adjustment screw	149	Choke lever
41	Cylinder paper gasket	95	Adjustment screw gear	150	Carburetor bracket gasket
42	Piston pin retaining ring	96	Pan head tapping screws	151	Intake flange
43	Piston pin	97	Brake pad	152	Keep circle
44	Piston	98	Brake plate nameplate	153	Carburetor
45	Anti-wear pads	99	Flange face nut	154	Double-ended stud
46	Needle roller bearings	100	Slotted socket	155	Intake elbow
47	Half round key	101	Sleeve limit spring	156	Hexagon socket screw
48	Crankshaft	102	Fuel tank shock absorber spring cover	157	Intake elbow shock absorber
49	Cylindrical pin	104	Large flat head self tapping screws	158	Oil inlet pipe
50	Box paper pad	106	Sleeve fixing spring	159	Bar
51	Right box	107	Tank	160	Chain
52	Limiting ejector rod	108	Trigger control arm	161	Bar protector

HGC5820-EX-RU251125