


HOS8145BL



NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW M8*16	16	STATOR
2	GASKET Φ8	17	LOWER COVER ASSEMBLY
3	SANDING PAD ASSY	18	LEFT AIR VENT
4	VACUUM TRAY	19	DUST DISCHARGE CONNECTOR 1
5	VACUUM FAN	20	SCREW ST3*6F
6	ECCENTRIC BLOCK ASSEMBLY	21	DUST DISCHARGE CONNECTOR 2
6-1	OUTPUT SHAFT	22	SCREW ST3*20
6-2	GASKET Φ12*24	23	CABLE
6-3	RING Φ31*26	24	SCREW ST3*16
6-4	BEARING 6001RS	25	SOCKET
6-5	BEARING 6001Z	26	RIGHT AIR VENT
6-6	RING Φ12	27	SCREW ST3*10F
6-7	ECCENTRIC BLOCK	28	PCB ASSY
7	FAN	29	Φ3.2 ROUND BUCKLE
8	CIRCLIP Φ22	30	LED CAP
9	SWITCH PLATE ASSEMBLY	31	1M DUST HOSE
9-1	MAGNET STEEL	32	SANDING PAPER 220#
9-2	SWITCH PLATE	33	WRENCH S5/85MM
10	SPRING	34	LABEL
11	UPPER COVER		
12	SCREW ST3*30		
13	ROTOR COVER		
14	DUST-PROOF WASHER		
15	ROTOR ASSEMBLY		
15-1	ROTOR		
15-2	BEARING 608 2RS		

HOS8145BL-EX-RU250121-1