


# HPG-6500I



NO.	DESCRIPTION
1	ENGINE ASSEMBLY
2	BOLTS/M10*1.5/25
3	ENGINE FIXING BASE PLATE 1
4	ENGINE FIXING BASE PLATE 2
5	BOLTS/M6*1/25
6	FLAT WASHER
7	FUEL TANK ASSEMBLY WITH TANK CAP
8	OIL SWITCH ASSEMBLY
9	NUT/M8*1.25
10	DAMPING SEAT
11	BOLT/M6*1/16
12	NUT/M6*1
13	BOLT/M8*1.25/16
14	NUT/M8*1.25
15	DAMPING RUBBER PAD
16	BRACKET PART-U TYPE
17	AXLE
18	WHEEL ASSEMBLY
19	LOCATING PIN
20	HANDLEBAR RETAINING PIN
21	HANDLEBAR TUBE ASSEMBLY
22	HANDLEBAR RUBBER SLEEVE
23	RACK COMPONENT
24	MOVABLE CROSS BEAM
25	BOLT/M6*1/12
26	CROSS RECESSED PAN HEAD SCREWS
27	CONTROL PANEL ASSEMBLY
28	STARTING PROTECTION RING
29	BOLT/M6*1/16
30	NUT/M6*1
31	BOLT/M5*0.8/12
32	INVERTER BRACKET 1
33	INVERTER BRACKET 2
34	INVERTER INNER COVER
35	INVERTER OUTER COVER
36	RUBBER CONNECTION SLEEVE
37	INVERTER PARTS
38	DC VOLTAGE REGULATOR
39	BATTERY HOOP BAND
40	BATTERY
41	BOLT M6*10
42	HARNESS PART/RED
43	HARNESS PART/BLACK
44	PROTECTIVE SLEEVE(UPPER)
45	PROTECTIVE SLEEVE(DOWN)

# hanskonner®


инструмент, в который верим

[Ханс Кённер]

# hanskonner®

инструмент, в который верим

[Ханс Кённер]



## HPG-6500I

NO.	DESCRIPTION
1	PANEL BACK COVER
2	PANEL BODY
3	DISPLAY METER
4	ONE KEY START BUTTON
5	PARALLEL SOCKET
6	EUROPEAN SOCKET
7	INDUSTRIAL SOCKET
8	GROUND SCREW
9	USB SOCKET/TYPER+C
10	ATS SOCKET
11	FLAMEOUT SWITCH
12	PUSH BUTTON START REMOTE CONTROL MODULE
13	16A OVER-CURRENT PROTECTOR

HPG-6500I-EX-SCRTT24001\_p

# hanskonner®

инструмент, в который верим

[Ханс Кённер]

# hanskonner®

инструмент, в который верим

[Ханс Кённер]

## ENGINE FOR HPG-6500I



NO.	DESCRIPTION	NO.	DESCRIPTION
0	CRANKCASE	C20	CYLINDER HEAD AIR GUIDE
A1	LOCATING PINS	C21	CYLINDER HEAD GASKET
A2	STARTER MOTOR PARTS	C22	CYLINDER HEAD COVER ASSEMBLY
A3	BOLT	C23	BOLT
A4	DIGITAL IGNITION	C24	EXHAUST GAS PIPE
A5	BOLT	D1	O-RINGS
B1	VALVE TAPPET	D2	OIL SENSOR
B2	BEARING 6206	D3	BOLT
B3	CRANKSHAFT ASSEMBLY	D4	BOLT
B4	CAMSHAFT ASSEMBLY	D5	ALUMINUM GASKET
B5	LOCATING PIN	E1	AIR INTAKE DOUBLE HEAD BOLT
B6	CRANKCASE COVER GASKET	E2	AIR INTAKE GASKET
B7	BEARING 6206	E3	CARBURETOR CONNECTING BLOCK
B8	OIL DIPSTICK ASSEMBLY	E4	CARBURETOR GASKET 1
B9	CRANKCASE COVER	E5	CARBURETOR GASKET 2
B10	BOLT	E6	CARBURETOR ASSEMBLY
B11	EXHAUST DOUBLE HEAD BOLT	E7	AIR FILTER GASKET
B12	MUFFLER GASKET	E8	NUT
B13	MUFFLER BRACKET	E9	BOLT
B14	BOLT	E10	FUEL LINE
B15	MUFFLER COMPONENTS	E11	CLAMPS
B16	ANTI LOOSENING NUTS	E12	PROTECTIVE SLEEVE
B17	BOLT	E13	RUBBER SLEEVE 1
C1	PISTON RING ASSEMBLY	E14	AIR FILTER ASSEMBLY
C2	PISTON	F1	OIL SEALS
C3	PISTON PINS	F2	STATOR
C4	PISTON PIN SNAP RING	F3	BOLT
C5	CONNECTING ROD ASSEMBLY	F4	CRIMP PLATE
C6	POSITIONING PIN	F5	BOLT
C7	CYLINDER HEAD GASKET	F6	ROTOR
C8	INTAKE VALVE	F7	NUT
C9	EXHAUST VALVE	F8	TRIGGER
C10	CYLINDER HEAD ASSEMBLY	F9	BOLT
C11	VALVE SPRING	F10	FRONT FAN
C12	INTAKE VALVE OIL SHIELD	F11	STARTER CUP
C13	VALVE SPRING SEAT	F12	BOLT
C14	VALVE LOCK CLIPS	F13	NUT
C15	SPARK PLUG	F14	BOLT
C16	BOLT	F15	RUBBER SLEEVE 2
C17	VALVE PUSH ROD	F16	RECOIL STARTER ASSEMBLY
C18	VALVE ROCKER ARM ASSEMBLY	F17	METAL WIRE CLAMPS
C19	ROCKER ARM SHAFT	F18	BOLT