

HRH0828RE

NO.	DESCRIPTION	NO.	DESCRIPTION
1	DUST CAP	54	SPRING
2	CIRCLIP $\Phi 14 \times 1.5$	55	CLUTCH
3	WASHER $\Phi 16$	56	ROCKER BEARING
4	CIRCLIP $\Phi 19 \times 2$	57	HK0910 NEEDLE BEARING
5A	LOCKING SLEEVE	58	ROCKER BEARING PRESS PLATE
7	WASHER FOR DUST CAP $\Phi 21 \times \Phi 32 \times 4$	59	SCREW M5X14
8	STELL BALL $\Phi 7.14$	60	CIRCLIP
9	RING SPRING FLORIATE WASHER	61	699 BEARING
10	SPRING	62	MIDDLE GEAR
11	SCREW ST4.2X40	63	SHIFT FORK
12A	FRONT HOUSING	64	SHIFT FORK SPRING
14A	SCREW ST4.2X16	65	609RS BEARING
15	HK0709 NEEDLE BEARING	66	BRACKET PRESS PLATE
16	NINE DENS WASHER	67	BEARING WASHER $\Phi 9 \times \Phi 13 \times 0.5$
17	SCREW ST4.2X12	68	ROTOR
18	OIL SEAL $\Phi 30 \times \Phi 41 \times 7$	69	607RS BEARING
19	BUSHING	70	BEARING COVER
20	HK3012 NEEDLE BEARING	71A	WIND GUIDE
21	CIRCLIP	72	SCREW ST3.5X14
22	WASHER $\Phi 30 \times \Phi 43 \times 1.5$	73	STATOR
23	SPRING	74	TERMINAL BOARD
24	BIG GEAR	75A	HOUSING
25	ROTARY SLEEVE	76	SWITCH CONTACT
26	WASHER	77	CARBON BRUSH HOLDER ASSEMBLY
27	INSULATION WASHER	78	TORSION SPRING
28	PIN $\Phi 2.5 \times 12$	79	CARBON BRUSH
29	CLUTCH DISK	80	COIL SPRING
30	CIRCLIP $\Phi 28 \times 1.5$	81A	HOUSING COVER
31	OIL SEAL $\Phi 9.2 \times \Phi 16 \times 5$	82A	SCREW ST4.2X30
32	POSITION-LIMITED SLEEVE OF IMPACT ROD	83	INTERNAL WIRE
33	IMPACT ROD	84	SWITCH
34	IMPACT ROD SLEEVE	85	CORD CLAMP
35	O-RING $\Phi 18 \times 3.5$	86	SCREW ST4.2X16
36	O-RING $\Phi 9.6 \times 3.5$	87	CORD SLEEVE
37	DAMPING BUSHING	89	CORD
38	CIRCLIP $\Phi 28 \times 2$	90	MODEL SELECTOR KNOB
39	PISTON	91	O-RING $\Phi 11 \times 2.5$
40	O-RING $\Phi 15.1 \times 3$	92	MODEL SELECTOR SPRING
41	CYLINDER	93	MODEL SELECTOR IRON CORE
42	CYLINDER PIN	94	LOCKING BUTTON
43	CYLINDER WASHER	95A	HANDLE STEEL RING
46	SCREW M4X10	96	T-BOLT
48	BRACKET BUSHING	97	HANDLE SEAT
49	BRACKET O-RING $\Phi 59.5 \times 5$	98	DEPTH GUAGE LOCK SPRING
50	BRACKET ASSEMBLY	99	DEPTH GUAGE LOCK
51	O-RING	100	DEPTH GUAGE
52	BRACKET PIN	102A	AUXILIARY HANDLE ASSEMBLY
53	BEVEL GEAR		