


# HRH1130AVS



NO.	DESCRIPTION	NO.	DESCRIPTION
1	DUST CAP	59	M5X16 CREW
2	SNAP RING14*1.5	60	SNAP RING
3	WASHER16*22*1.6	61	699 BEARING
4	SNAP RING19*2	62	GEAR SHAFT
5	LOCKING SLEEVE	63	MODEL SELECTOR FORK
6	WASHER 24.8*30.6*1	64	MODEL SELECTOR FORK SPRING
7	THICK WASHER21*32*6	65	609BEARING
8	STEEL BALL	66	HOLDING PLATE
9	WASHER	67	BEARING WASHER
10	SPRING	68	ARMATURE
11	SCREW ST4.2*40	69	607BEARING
12	GEAR BOX	70	SPRING
15	NEEDLE ROLLER BEARING HK0709	71	WIND PROOF BOARD
16	NINE TEETH WASHER	72	SCREW ST3.5*14
17	SCREW ST4.2*16	73	STATOR
18	OIL SEA	74	INDUCTOR
19	BUSHING	75	F-BUSHING
20	NEEDLE ROLLER BEARING HK3012	76	GUIDING PART
21	FLAT SNAP RING	77	STATOR HOLDER
22	WASHER30*43*1.5 (65MN)	78	ANTI-VIBRATION RUBBER PART
23	SPRING	79	SPRING
24	BIG GEARING	80	SPRING SOCKET
25	ROTATION SLEEVE(NEW BARREL)	81	MOTOR HOUSING
26	WASHER	82	COPPER CONTACT SHEET
27	PLASTIC SPACING RING	83	BRUSH HOLDER
28	POSITION-KEY 2.5X12	84	SPRING
29	HOLDING RING	85	CARBON BRUSH 5*8*19
30	SNAP RING28*1.5	86	POWER SWITCH
31	OIL SEAL 9.2X16X5	87	CONNECTING WIRE 98MM(M+M)
32	BUSHING	88	BACK COVER
33	STRIKCR	89	SCREW ST4.2*22
34	BUSHING	90	MODEL SELECTOR KNOB
35	O-RING 18*3.5	91	MODEL SELECTOR O-RING 11X2.5
36	O-RING 9.6X3.5	92	MODEL SELECTOR SPRING 5.8X44
37	HOLDING BUSHING	93	MODEL SELECTOR IRON CORE
38	SNAP SPRING 28*2	94	MODEL SELECTOR ELEMENT
39	PISTON	95	CLAMPING BAND
40	PISTON O-RING 17X3	96	T SCREW
41	CYLINDER	97	SUPPORT CLAMP
42	CYLINDER PIN	98	SPRING
43	WASHER	99	LOCKING BUTTON
46	M4X10 SELF-TAPPING BOLT	100	DEPTH GAUGE
48	FLANGE BUSHING	101	NUT M8
49	FLANGE O RING	102	AUXILIARY HANDLE (RUBBER)
50	FLANGE	103	SCREW ST4.2*16
51	609BEARING O-RING 23.8X22	104	CORD CLAMP
52	GEAR FIXED PIN	105	SCREW ST4*16
53	38 DENS SLANTING GEAR	106	CORD SLEEVE
54	CLUTCH SPRING	107	CABLE 4 M 2X01.0MM
55	CLUTCH	108	CONNECTING WIRE 100MM
56	SWASH BEARING	110	WOOL FELT
57	HK0910 NEEDLE BEARING		
58	HOLDING PLATE		