


MC8835L



| NO. | DESCRIPTION | NO. | DESCRIPTION |
|-----|----------------------|-----|---------------------------|
| 1 | LEFT COVER | 30 | BREATHER PIPE |
| 2 | RUBBER FOOT | 31 | CABLE |
| 3 | CONNECTION ROD | 32 | CIGARETTE PLUG |
| 4 | BEARING | 33 | HANDLE RUBBER PAD (left) |
| 5 | ECCENTRIC WHEEL | 34 | HANDLE RUBBER PAD (right) |
| 6 | BRACKET | 35 | QUICK CONNECTOR |
| 7 | BEARING | 38 | LED CHIP |
| 8 | MOTOR HOUSING | 39 | LED COVER |
| 9 | STATOR | 101 | CONNECTION ROD ASSEMBLY |
| 10 | ADJUST PIECE | 102 | MOTOR HOUSING AND STATOR |
| 11 | ROTOR | B1 | SCREW |
| 12 | BRUSH HOLDER | B2 | SCREW |
| 13 | CARBON BRUSH | B3 | BOLT |
| 15 | BEARING HOLDER | B4 | CIRCLIP |
| 16 | ON/OFF SWITCH | B6 | SPRING |
| 17 | RIGHT COVER | B7 | SCREW SPRING |
| 18 | CABLE SLEEVE | B8 | RIVET |
| 19 | PISTON RING | B10 | BOLT |
| 20 | PISTON PRESSURE RING | | |
| 21 | AIR WASHER | | |
| 22 | O RING | | |
| 23 | CYLINDER BUSH | | |
| 24 | RADIATOR | | |
| 25 | AIR PROOF LOCK | | |
| 26 | HANDLE | | |
| 27 | PRESSURE PIECE | | |
| 28 | CYLINDER COVER | | |
| 29 | AIR PRESSURE METER | | |

RU-ST20161117

Sturm!
нас рекомендуют друзья