



P1012

| NO. | DESCRIPTION | NO. | DESCRIPTION |
|-----|--|-----|--|
| 1 | SELF LOCKING CROSS PAN HEAD SCREW ST4.2×14-F | 36 | SOCKET HEAD CAP SCREW M5×6 |
| 2 | PARAMETER LABELING | 37 | BATTEN |
| 3 | SIDE SHIELD | 38 | PLANE BLADE |
| 4 | BRUSH BOX 6×9×20.5 | 39 | BLADE SHIM |
| 5 | CARBON BRUSH | 40 | BLADE PIVOT |
| 6 | BRUSH BOX LID 11×9×2.3 | 41 | BEARING 6000-2Z |
| 7 | SELF LOCKING CROSS PAN HEAD SCREW WITH WASHER ST4.2×10 | 42 | LARGE BELT WHEEL |
| 8 | BAFFLE PLATE | 43 | HEXAGON THIN NUT M8 |
| 9 | TORSIONAL SPRING Φ11×Φ1×3 | 44 | LOGO LABELING |
| 10 | COMPRESSION SPRING Φ1.85×Φ0.45×10 | 45 | SELF LOCKING CROSS PAN HEAD SCREW ST4.2×30-F |
| 11 | STEEL BALL Φ2.5 | 46 | BELT COVER |
| 12 | SMALL STEEL BUSHING | 47 | BELT 4PJ243 |
| 13 | UPPER HAND WHEEL SHIELD | 48 | SMALL BELT WHEEL |
| 14 | CONNECTING SCREW | 49 | BEARING 608-2Z |
| 15 | BOTTOM HAND WHEEL SHIELD | 50 | MIDDLE SHIELD |
| 16 | DIAL | 51 | ROTOR |
| 17 | HOUSING | 52 | BREAK WIND RING |
| 18 | THICK HEXAGON NUT M6 | 53 | SELF LOCKING CROSS PAN HEAD SCREW ST4.2×55-F |
| 19 | DUST BOARD | 54 | STATOR |
| 20 | COMPRESSION SPRING Φ11.5×Φ2.3×5 | 55 | BEARING 626-2Z |
| 21 | FRONT BASEBOARD | 56 | COMPRESSION KNOB |
| 22 | SWITCH | 57 | INVERTED BAFFLE GROUP |
| 23 | CAPACITANCE | 58 | SWITCH CONTROL BLOCK |
| 24 | DECORATIVE BLOCK | 59 | INVERTED SUPPORT GROUP |
| 25 | HANDLE COVER | 60 | LOCKING KNOB |
| 26 | SELF LOCKING CROSS PAN HEAD SCREW ST4.2×10-F | 61 | CUP HEAD SQUARE NECK BLOT M6×12 |
| 27 | BACK BASEBOARD | 62 | DEPTH RULE |
| 28 | SELF LOCKING CROSS PAN HEAD SCREW ST4.8×16-F | 63 | ACCESSORY FIXED BLOCK |
| 29 | SUPPORTING BLOCK | 64 | HEX WRENCH 2.5 |
| 30 | TORSIONAL SPRING Φ6.3×Φ0.4×3.5 | 65 | OPEN-END WRENCH 8 |
| 31 | CABLE CLAMP | 66 | DUST BAG ASSEMBLY |
| 32 | CABLE SHEATH | 67 | ANGLE IRON |
| 33 | CABLE | 68 | PARALLEL FENCE |
| 34 | BEARING 607-2Z | 501 | BLADE BODY |
| 35 | HEX HEAD CAP SCREW M5×7 | | |

P1012-EX-RU240327-2