



Sturm!
нас рекомендуют друзья

RS8815

NO.	DESCRIPTION	NO.	DESCRIPTION
1	CABLE	23	GEAR CASE
2	SWITCH	24	SCREW ST4X35
3	LEFT HANDLE	25	BEARING 608
4	CAPACITOR	26	CIRCLIP
5	RIGHT HANDLE	27	BEARING 6000
6	SCREW ST4X12	28	BIG GEAR
7	KNOB SPRING	29	OUTPUT SHAFT
8	KNOB	30	PIN
9	BRUSH COVER	31	NEEDLE
10	CARBON BRUSH	32	RECIPROCATING ROD ASSEMBLY
11	BRUSH HOLDER	33	PRESSURE COVER
12	HOUSING	34	SCREW M4X18
13	TENSION SPRING	35	MIDDLE COVER
14	STATOR	36	TOP COVER
15	BOLT ST4X55	37	SCREW M5X12
16	BEARING SLEEVE	38	SAW FRAME
17	FAN SHROUD	39	SCREW M5X10
18	BEARING 607	40	SCREWM5X12
19	ROTOR	41	SHELL
20	SCREW M4X8	42	LIGHT COVER
21	BEARING 6000	44	SCREW ST4X14
22	CIRCLIP	45	LIGHT ASSEMBLY

RS8815-EX-RU241121

Sturm!
нас рекомендуют друзья