




SF5001

NO.	DESCRIPTION
1	CENTER PIECE
2	FRONT GRILL
3	SPINNER
4	BLADE
5	PLASTIC NUT
6	REAR GRILL
7	FRONT ENCLOSURE
8	MOTOR
9	CAPACITOR
10	OSCILLATING
11	REAR ENCLOSURE
12	OSCILLATING ARM
13	NECK
14	FAN BODY
15	TIGHTEN SCREW
16	POWER CORD
17	COLUMN
18	COLUMN SCREW
19	ROUND BASE COVER
20	ROUND BASE
21	PIANO-KEY

SF5001-ex-RUS221008