





WP9712SW

NO.	DESCRIPTION	NO.	DESCRIPTION
A1	SCREW	A31	TOP COVER
A3	BOLT	A32	WASHER
A4	WASHER	A33	FLOW SWITCH
A5	CUTTING BLADE	A34	SCREW
A7	PUMP BODY	A35	CABLE PRESSER
A8	IMPELLER	A36	CABLE PROTECTOR
A9	BOLT	A37	HANDLE
A10	SCREW	A38	CABLE & PLUG
A11	OIL SEAL	A39	CABLE PROTECTOR
A12	CHAMBER COVER	A40	CABLE
A13	"O" RING	A41	PROTECTOR BOX
A14	MECHANICAL SEAL	A42	SCREW
A15	"O" RING	A43	PROTECTOR COVER
A16	OIL CHAMBER	A44	CURRENT OVERLOAD PROTECTOR
A17	SCREW	A45	RUBBER COVER
A19	FLAT KEY	A46	HOUSING WITH STATOR
A20	"O" RING	A48	OUTLET
A21	BEARING	A50	CUTTER PLATE
A22	ROTOR	A51	SPRING WASHER
A23	BEARING	A52	FLAT KEY
A24	MOTOR HOUSING		
A25	STATOR		
A26	COVER PLATE		
A27	"O" RING		
A28	CAPACITOR		
A29	"O" RING		
A30	SCREW		

RU-ST20161209
VER: 2.1