



WP9742VS

NO.	DESCRIPTION	NO.	DESCRIPTION
A1	DISCHARGE SCREW	A19	MOTOR END COVER
A2	PUMP BODY FRONT COVER	A20	SPRING WASHER(OPTIONAL)
A3	SCREW	A21	CABLE & PLUG
A4	MECHANICAL SEAL 1	A22	SCREW
A5	MECHANICAL SEAL 2	A23	CAPACITOR
A6	SCREW	A24	CAPACITOR COVER
A7	RUBBER RING	A25	PRESSURE TANK
A8	MOTOR FRONT COVER	A26	PRESSURE SWITCH
A9	BEARING 6201	A27	PLUG SCREW
A10	PIN	A28	PUMP BODY
A11	ROTOR	A29	INLET CHECK VALVE
A12	STATOR	A30	INLET PORT
A13	BASE	A31	CIRCLIP
A14	STATOR HOUSING	A32	IMPELLER
A15	BEARING 6201	A33	"O" RING
A16	MOTOR FIX SCREW	A34	"O" RING
A17	FAN	A35	"O" RING
A18	FAN COVER	A36	CABLE SLEEVE

RU-ST20151124 VER:2.1