



WP9742VS

NO.	DESCRIPTION	NO.	DESCRIPTION
B1	DISCHARGE SCREW	B19	MOTOR END COVER
B2	PUMP BODY FRONT COVER	B20	SPRING WASHER(OPTIONAL)
B3	SCREW	B21	CABLE & PLUG
B4	MECHANICAL SEAL 1	B22	SCREW
B5	MECHANICAL SEAL 2	B23	CAPACITOR
B6	SCREW	B24	CAPACITOR COVER
B7	RUBBER RING	B25	PRESSURE TANK
B8	MOTOR FRONT COVER	B26	PRESSURE SWITCH
B9	BEARING 6201	B27	PLUG SCREW
B10	ROTOR	B28	PUMP BODY
B11	STATOR	B29	INLET CHECK VALVE
B12	BASE	B30	INLET PORT
B13	STATOR HOUSING	B31	CIRCLIP
B14	BEARING 6201	B32	IMPELLER
B15	MOTOR FIX SCREW	B33	"O" RING
B16	FAN	B34	"O" RING
B17	FAN COVER	B35	"O" RING
		B36	CABLE SLEEVE

RU-ST20190117 VER3.1

