



WP9775SW

NO.	DESCRIPTION	NO.	DESCRIPTION
1	HEX. BOLT M5*10	23	CROSS PAN HEAD SCREW M4*6
2	POWER CORD&PLUG ASSEMBLY	24	OVERHEATING PROTECTOR
3	CORD GUARD	25	O SEAL RING Ø80*2.65
4	CORD GUARD CLAMP	26	MECHANICAL SEAL ASSEMBLY
5	HEX. BOLT M6*8	27	FLOAT SWITCH ASSEMBLY
6	HANDLE	28	O SEAL RING
7	HEX. BOLT M6*35	29	DEFLATION SCREW M8*10
8	TOP COVER	30	HEX NUT M6
9	O SEAL RING Ø130*2.65	31	SPRING WASHER
10	PAN HEAD SCREW M4*6	32	STATOR
11	CAPACITOR CLIP	33	MOTOR HOUSING
12	CAPACITOR	34	WATER OUTLET
13	PAN HEAD SCREW M4*8	35	HEX. BOLT M8*35
14	WIRE SLEEVE	36	RUBBER GASKET
15	TERMINAL CAP	37	PUMP HEAD
16	MOTOR COVER	38	HEX. NUT M8
17	BEARING 6202	39	SKELETON OIL SEAL Ø28*14
18	ROTOR	40	IMPELLER
19	BEARING 6203	41	WAVE WASHER
20	FLAT KEY 5*10	42	HEX NUT M10
21	EARTHING MARK	43	PUMP BASE
22	WAVE WASHER	44	HEX. SCREW M6*16
		999	STATOR WITH HOUSING(30+31+32+33)

ST20111212-01

POWER • GAS • HAND • TOOLS

POWER • GAS • HAND • TOOLS