




ДУ1-1000

NO.	DESCRIPTION	SPEC.	NO.	DESCRIPTION	SPEC.
A1	SCREW	M6*25	A25	LONG LEAD	
A2	CHUCK		A26	SHORT LEAD	
A3	SCREW	ST4.2*32	A27	UPPER BRUSH HOLDER	
A4	GEAR BOX		A28	DIRECTION SWITCH	
A5	BEARING	6003-2Z	A29	SCREW	ST2.9*10
A6	CIRCLIP	Φ35	A30	PIECE	Φ3
A7	SPINDLE		A31	SPING	
A8	STEEL BALL	Φ4	A32	DOWM BRUSH HOLDER	
9	GEAR		34	SWITCH	
A10	RETAINING RING	Φ10	A35	CAPACITOR	
A11	SPRING		A36	CORD SLEEVE	
A12	IMPACT GEAR		A37	CORD & PLUG	
A13	BEARING	608-2Z	A38	BOLT	
A14	MIDDLE COVER		A39	DEPTH GAUGE	
A15	ANTI-OIL COVER		A40	UPPER HANDLE	
A16	BEARING	608-2Z	A41	DOWN HANDLE	
17	ROTOR				
A18	BEARING	627-2Z			
19	STATOR				
A20	IMPACT/DRILL CHANGE BUTTON				
A21	CHANGE PLATE				
A22	HOUSING				
A23	SCREW	ST4.2*16			
A24	CARBON BRUSH				

DU1-1000-EX-RUS201016
VER2.1