


# ПР-2610



NO	DESCRIPTION	NO	DESCRIPTION
1	PROTECTIVE SLEEVE ASSY	9-3	O- RING
1-1	PROTECTIVE CAP	9-4	OIL CORE
1-2	WASHER	9-5	BEARING 609
1-3	SNAP RING	9-6	BEARING PLATE
1-4	RETAINING RING	9-7	SCREW M4X10
1-5	SNAP RING 19X2	9-8	WASHER
1-6	PROTECTIVE SLEEVE	10	HOLDING PLATE
1-7	THRUST RING	11	MIDDLE SHAFT ASSY
1-8	BALL 7.14	11-1	MIDDLE SHAFT
1-9	HOLDING PLATE	11-2	BEARING 699
1-10	PAGODA SPRING	12	FORK
2	DRILL BUSHING ASSY	13	FORK SPRING CLIP
2-1	DRILL BUSHING	14	DRIVE END SHIELD HK0908
2-2	O RING	14-1	BEARINGHK0908
2-3	OIL SEAL	14-2	YAW BEARING
2-4	LIMIT RING	15	NEEDLE BEARINGK 15x18x14.8
2-5	IMPACT BOLT	16	GEAR
3	ROLLER	17	SURPORT SPRING
4	SCREW ST4.8×45	18	SURPORT BUSHING
5	GEAR HOUSING ASSY	19	ROTOR
5-1	GEAR HOUSING	20	BEARING 607
5-2	OIL SEAL 41×7×30	21	RUBBER SLEEVE
5-3	BEARING SLEEVE ASSY	22	AIR RING
5-3-1	NEEDLE SLEEVE HK3012	23	SCREW ST3.9×16
5-3-2	BEARING SLEEVE	24	STATOR
5-4	NEEDLE SLEEVE HK0709	25	SUPPRESSOR BOX
5-5	TAB WASHER	26	HOUSING
5-6	SCREW ST4.2×13	27	SWITCH CONTACT
6	BUTTON ASSY	28	BRUSH HOLDER ASSY
6-1	RED BUTTON	28-1	BRUSH HOLDER
6-2	BUTTON SPRING	28-2	COPPER BRUSH HOLDER
6-3	BUTTON	28-3	BRUSH HOLDER CLIP
6-4	O RING	28-4	CARBON BRUSH
7	RATCHET SLEEVE ASSY	28-5	COIL SPRING
7-1	ROTATE OUT RING	29	SWITCH BUTTON
7-2	ROTATE WASHER	30	INDUCTANCE
7-3	ROTATE SPRING	31	SWITCH ASSY
7-4	BIG GEAR	31-1	SWITCH
7-5	PIN	31-2	CABLE
7-6	CATCH DISC	31-3	CROMMET
7-7	ROTATE INNER RING1	31-4	CABLE GUARD
7-8	RATCHET SLEEVE	32	CABLE CLIP
7-9	GUIDE BUSHING	33	SCREW ST3.9×16
7-10	GUIDE BUSHING O RING	34	BACK HOUSING
7-11	LIMIT BUSHING O RING	35	SCREW ST4.2×19
7-12	LIMIT BUSHING	36	HANDLE ASSY
7-13	ROTATE INNER RING2	36-1	HANDLE BAND
8	PISTON ASSY	36-2	T-BOLT
8-1	PISTON	36-3	CLAMP OLDER
8-2	PISTON O RING	36-4	RED BUTTON
8-3	CYLINDER	36-5	HANDLE SPRING
8-4	U-SHAPED RING	36-6	HANDLE
8-5	CYLINDER PIN	37	RULER
9	SUPPORT ASSY	38	O-RING
9-1	SUPPORT BUSHING	39	SCREW ST4.2×16
9-2	SUPPORT		