



## ПЦС-9926

NO.	DESCRIPTION	NO.	DESCRIPTION
B1	NUT M8	B29	SCREW ST4X12
B2	SIDE COVER	30	OIL PUMP CLAMP PLATE
B3	NUT M8LEFT	B31	OIL PIPE
B4	SPRING WASHER	32	OIL PUMP
B5	WASHER	B33	MIDDLE COVER
B6	SPRING	34	BEARING 6201
B7	CHAIN WHEEL	35	ROTOR
B8	SLIP NUT	36	BEARING 6200
B9	SCREW	B37	FAN GUARD
10	SAW CHAIN	38	SCREWST4.8X55
11	GUIDE BAR	39	STATOR
B12	SCREW ST4.8X20	B40	HOUSING
B13	GEAR BOX	B41	SCREWST5X35
B14	BOLTM8X30	B42	BRUSH HOLDER
B15	SCREWST4.2X25	43	CARBON BRUSH
B16	GUIDE PLATE	B44	BRUSH COVER
B17	SCREW M5X12	B45	NUT M5
B18	HANDLE	46A	SWITCH
B19	BEARING 6202	B48	SCREW ST4X16
20	KEY	49	SCREW ST4.2X14
21	SHAFT	50	CORD CLAMP
22	GEAR	51	CORD SLEEVE
23	WASHER	52	POWER CORD
24	CIRCLIP	53	CAPACITOR
25	BEARING 6001	54	TRIGGER
B26	TANK CAP	55	SPRING
B27	OIL TANK	B56	HOUSING COVER
28	OIL PIPE	57	OIL SEAL

RU-SO20190710  
Ver.1.3