




УШС-90122

NO.	DESCRIPTION	NO.	DESCRIPTION
1	LOCK NUT	26	SCREW M4X8
2	GRINDING WHEEL	27	ROTOR
3	INNER FLANGE	28	BEARING 607
4	WHEEL GUARD	29	BEARING BUSHING
5	SCREW M5X25	30	BAFFLE PLATE
6	SQUARE NUT M5	31	SCREW ST3.9X50
7	SPINDLE	32	STATOR
8	WOODRUFF KEY 3X10	33	SWITCH BUTTON
9	SCREW M4X14	34	HOUSING
10	SPRING WASHER $\Phi 4$	35	HOUSING COVER
11	PLAIN WASHER $\Phi 4$	36	SWITCH POLE
12	FRONT COVER	37	BACK COVER
13	BEARING 6001	38	SCREW ST3.9X10
14	SCREW ST3.9X8	39	CABLE GUARD
15	BIG GEAR	40	CABLE
16	CIRCLE FOR SHAFT $\Phi 10$	41	SCREW ST2.9X8
17	OIL BEARING $\Phi 12 \times \Phi 8 \times 10$	42	CARBON BRUSH
18	CIRCLE FOR SHAFT $\Phi 6$	43	CARBON
19	GEAR BOX	44	INDUCTANCE
20	SELF-LOCK SPING	45	CAPACITOR
21	SELF-LOCKPIN	46	SWITCH
22	SCREW ST3.9X16	47	STRAIN RELIEF
23	PINION GEAR	48	SCREW ST3.9X12
24	BEARING 608	49	HANDLE
25	BEARING COVER	50	SPANNER

RU-SO20180122