

## MC8850

| NO. | DESCRIPTION | NO. | DESCRIPTION |
|---|---|---|---|
| 1 | LEFT COVER | 26 | HANDLE |
| 2 | RUBBER FOOT | 27 | PRESSURE PIECE |
| 3 | CONNECTION ROD | 28 | CYLINDER COVER |
| 4 | BEARING 607 | 29 | AIR PRESSURE METER |
| 5 | ECCENTRIC WHEEL | 30 | BREATHER PIPE |
| 6 | BRACKET | 31 | CABLE |
| 7 | BEARING 608 | 32 | CIGARETTE PLUG |
| 8 | MOTOR HOUSING | 33 | HANDLE RUBBER PAD (LEFT) |
| 9 | STATOR | 34 | HANDLE RUBBER PAD (RIGHT) |
| 10 | ADJUST PIECE | 35 | QUICK CONNECTOR |
| 11 | ROTOR | 101 | CONNECTION ROD ASSEMBLY |
| 12 | BRUSH HOLDER | 102 | MOTOR HOUSING AND STATOR |
| 13 | CARBON BRUSH | B1 | SCREW |
| 15 | BEARING HOLDER | B2 | SCREW |
| 16 | ON/OFF SWITCH | B3 | BOLT |
| 17 | RIGHT COVER | B4 | CIRCLIP |
| 18 | CABLE SLEEVE | B6 | BRUSH SPRING |
| 19 | PISTON RING | B7 | SCREW |
| 20 | PISTON PRESSURE RING | B8 | RIVET |
| 21 | AIR WASHER | B10 | BOLT |
| 22 | "O" RING | | |
| 23 | CYLINDER BUSH | | |
| 24 | RADIATOR | | |
| 25 | AIR PROOF LOCK | | |

RU-ST20161117

Sturm! ® нас рекомендуют друзьям